


COMFORT ZONES WARDROBE HEIGHT AND DEPTH

In order to plan your wardrobe sensibly and ergonomically, there are a few things to consider. For example, your body size height as well as your space requirements and, of course, the wardrobe's area of use play a major role. That's why we're giving you a few tips to help you put together the perfect wardrobe for you.

The different comfort zones (**CF I - IV**) result from the user's body size. The accommodation of frequently or regularly used clothing should be planned in **CF I** and **CF II**. With increasing age, the comfort zones shift considerably. It is therefore all the more important that the planned interior system also adapts to your living situation. Accessories such as pull-outs, shelves, wire baskets or clothes lifts play a major role especially in **CF II** to **CF IV** and can be easily retrofitted with **raumplus** interior systems.



- CF I** Comfort Zone I
- CF II** Comfort Zone II
- CF III** Comfort Zone III
- CF IV** Comfort Zone IV

